Fuse #	<u>Description</u>	Amps
1	Heated washer jets	5
2	Turn signals flasher unit	10
3	Headlight washer, illumination of glove compartment, engine compartment,	5
	climate control, automatic transmission, instrument cluster	
4	License plate light	5
5	Instrument cluster, seat heating, test connection for cruise control, bulb	10
	monitor for auto-check control, Automatic transmission display, switch	
	lighting, irror switches and actuators, airbag warning light, outside	
	temperature indicator, Climate control	
6	Central locking system	5
7	Anti-lock brake system	10
8	Vacant	
9	Mirror heating	10
10	Vacant	
11	Cruise control (automatic transmission)	5
12	On board diagnostic system	10
13	Brake lights	10
14	Interior lights, reading lights, anti-theft alarm system, vanity mirror	10
15	Instrument cluster, power windows, climate control, automatic transmission	10
16	Anti-lock brake system, Anti-Slip-Regulation	5
17	Heated door locks	10
18	High beam right	10
19	High beam left	10
20	Low beam right	15
21	Low beam left	15
22 23	Tail and side marker right Tail and side marker left	5 5
24	Wiper and washer system	25
25	Blower for heating, climate control	30
26	Rear window defogger, mirror heating	30
27	Rear window wiper	15
28	Fuel pump	15
29	Engine timing	20
30	Sun roof	20
31	Tail lights, cruise control, automatic transmission	15
32	Engine timing	20
33	Cigarette lighter	15
34	Engine timing	15
35	Trailer receptacle	30
36	Fog lights	15
37	Radio	20
38	Luggage compartment light, central locking system	15
39	Emergency flasher	15
40	Horn	25
41	Anti-lock brake system	25
42	Vacant	
43	Vacant	
44	Seat heating	30

